

## WINE BOTTLE STOPPER KITS INSTRUCTIONS

Using a 6mm drill, drill a hole in a piece of wood a bit longer than the length of the screw on the wine bottle stopper kit. Screw the threaded end of the wine bottle stopper mandrel into this hole until the wood shoulders against the round stop collar. Mount the shaft of the mandrel onto your lathe using a chuck, drill chuck or our drill driver for the B shaft. Support the other end of the wood with your live tail stock center. Turn the wood to the desired shape.

Unscrew the mandrel from the wood. Glue the wine bottle stopper into the hole in the wood. We recommend using two-part epoxy glue. Apply a liberal amount of glue but not so much as to have it run out of the hole and mar the wood.